











# HARLEM BASKET BOARD


420414

## ATTENTION!!!

Check the product before each use for stability or damage.  
 Make sure all the bolts are tightened before each use.  
 Adult assembly only and for domestic use only.

**8+**

|  |  |  |   |  |
|--|--|--|---|--|
| <p>#1</p>  <p>Backboard<br/>1pc</p> | <p>#2</p>  <p>Rim<br/>1pc</p>                         | <p>#3</p>  <p>Net<br/>1 pc</p>    | <p>#4</p>  <p>Wall plug<br/>3 pcs</p> | <p>#5</p>  <p>Bolts<br/>3 pcs</p>   |
| <p>#6</p>  <p>Washer<br/>3 pcs</p>  | <p>#7</p>  <p>Backboard Connecting Plate<br/>1 pc</p> | <p>#8</p>  <p>Bolts<br/>4 pcs</p> | <p>#9</p>  <p>Nuts<br/>8 pcs</p>     | <p>#10</p>  <p>Washer<br/>4 pcs</p> |



INTERSPORT International Corporation Europe B.V.  
 Van Diemenstraat 186, 1013CP, Amsterdam, Netherlands  
 inquiries@intersport.com



**WARNING**

This basketball backboard is for domestic use only and not for commercial use.  
 Do not hang out of the rim or any other components.  
 Do not wear jewellery while playing which might get caught in the net or catch it on other components.  
 Do not allow children to move or adjust the basketball backboard.  
 Check the product before each use for stability or damage. Make sure all the bolts are tightened before each use.  
 Not suitable for children under 36 months, small parts, choking hazard. Add Adult assembly only.